





Use Instructions

1.P2500 Extra Battery should be used with B2500, it cannot be used separately. 2. Short press the Main Power Button to turn on the product, the indicator will light up.

How to use it:

- The product enters sleep mode after 5 minutes of idle operation; the indicator will automatically turn off. When the product senses any load change or operations, the indicator will automatically light up. To turn the indicator on or off, please short press the Main Power Button. 3.To power off the product, press and hold the Main Power Button.
- The default product standby time is 2 hours. With other Power Buttons turned off and no other load access for 2 hours, the product will automatically shut down. 4.For use along with B2500
- P2500 Extra Battery can be uesd with B2500. A B2500 can support up to two P2500 Extra Battery to meet more extensive capacity requirements.

Use Instructions Please carefully read the following notes before using: 1. Before connecting the Extra Battery to the B2500, please make sure to power off the B2500 and P2500 2. After connecting the P2500 Extra Battery to B2500, you need to make sure that the Extra Battery icons appear on both the P2500 Extra Battery and the Extra Battery LED screen. Charge or discharge the P2500 Extra Battery after you have seen both icons. 3. DO NOT connect the P2500 Extra Battery to B2500 while discharging or charging; if you need to remove the Extra Battery Cable, please make sure that the P2200 Extra Battery and B2500 are both powered off. 4. DO NOT touch the metal Extra Battery Port with your hands or other objects. Gently wipe it clean with a dry cloth when unrelated materials are attached to the metal port. 5. Tightly connect the Extra Battery Cable with B2500 and the P2500 Extra Battery. Failing to comply may heat the connection and affect the device's performance or lead

Operating Temperature range

to a fire.

Low temperature may affect the battery capacity of the product, The product can be charged in a temperature range of 0°C-50°C. Charge the product when the temperature is below 0°C, We recommend placing the product in an insulated cooler or other temperature conditions. The product can be used in the temperature range of-10°C-50°C. In order to extend the service life of the battery, it is recommended to use this product in the environment of 20°C to 30°C.

Frequently Questions & Answers

What is the battery type?

- Can the product be taken on the aircraft?
- No, According to the airline transportation standards, 100Wh capacity of lithium battery can not board the aircraft.
- How to estimate the working time of the product?
- The LED display of this product can help you better understand the working status of the power supply.
- Before storing, please turn off the product first, and then store it in a dry, ventilated place at room temperature. Do not place it near water sources. For long-term storage, please discharge the battery to 30% and recharge it to 60% every three months to extend its battery life.

Chemical Composition of Toxic and Harmful Substances

Part	Toxic and harmful substances or chemical elements						
¦ Name	Pb	Hg	Cd	Cr(VI)	PBB	PBDE	O: The content of hazardous substances in homogeneous materials all components are requirement specified in GB-T 26572. X: The content of hazardous substance in at lone of the average materials of the part excethe limit requirement of GB-T 26572, and the no mature alternative in the industry at preswhich meets the environmental protection requirements of the EU RoHS directive. This information for reference purposes only does not represent a binding agreement. Pro (Color, Size, OSD, etc.) in kind prevail.
Product shell	0	0	0	0	0	0	
Circuit module	[x	0	. 0	0	0	0	
button	0	0	0	0	0	0	
Small hardware		0		0	0	0	
Charging Cable	0	0	0	0	0	0	
Battery		0	0	0	0	0	

Warranty and Contact Information

Under normal use of the product, it will not affect the result of defective workmanship and materials used in the product: This warranty period describes the complete and exclusive warranty obligations of the product, and we will not assign or authorize anyone to be responsible for any other products.

Product warranty period of 10 years. In all cases, the warranty period starts from the date of purchase by the consumer. In order to ensure the start date of the warranty period, the consumer needs to provide proof of purchase or other reasonable supporting documents.

The following conditions are not covered by the warranty

1.The appearance of the product is damaged after use.

2. Unauthorized disassembly and maintenance of non-professionals. 3.Performance problems caused by human factors.

4. Damage caused by natural disasters, lightning Strikes, accidents and other irresistible factors. How to get warranty service

You can contact our customer service through our official website or e-commerce platform. Thank you for your cooperation!

Marstek Energy Co., Limited

Add:Rooms 1318-19,13/F,Hollywood Plaza,610 Nathan Road Mongkok,Kowloon,Hong Kong. Tel:+86 400-115-6188 Email: support@marstekenergy.com

Made in china

Web: www.marstekenergy.com

